



Editorial Contact:

Brittney Larson
CPC
Tel: +1 651-603-2610
Email: Brittney.Larson@cpcworldwide.com



CPC Announces More Options to the Most Popular Polypropylene Plastic Coupling Platform

Options make it easier to connect to plastic manifold applications

St. Paul, Minn. – Feb. 10, 2015 – [CPC \(Colder Products Company\)](#), the leading provider of quick disconnect couplings and fittings for plastic tubing, announces the further expansion of its [PMC12 Series](#) quick disconnect couplings with options to simplify connections for plastic manifolds. With the new SAE straight thread port options, OEMs can now easily incorporate quick disconnect couplings into their plastic manifolds applications.

“The mounting style of the new PMC12 SAE straight thread ports offers several advantages over pipe threads including a quicker and more repeatable installation, and eliminates the need for thread tape or sealant,” says Grant Wilhelm, senior design engineer for medical markets at CPC. “SAE straight threads feature a more consistent mounting depth because the threads are not tapered and a robust o-ring on the straight thread that provides a secure seal.”

The new polypropylene PMC12 with SAE straight thread ports are perfect for threading couplings into acrylic manifolds that can easily be cracked if excessive force is used when sealing the couplings to the manifold. The SAE straight thread ports eliminate the need for a thread sealant, which is typically required for NPT pipe threads, thus making SAE straight thread ports a cleaner solution.

New PMC12 plastic [quick disconnect](#) couplings with SAE straight thread ports are ideal for applications within In Vitro Diagnostics (IVD) including reagent handling systems, and in printing and ink handling industries.

For more information about how your fluid handling application will benefit from integrating SAE straight thread ports, or any of the other 10,000+ innovative connection solutions CPC offers, visit us online at cpcworldwide.com.

#

About CPC

CPC (Colder Products Company) is the leading provider of quick disconnect couplings, fittings and connectors for life sciences, industrial and chemical handling markets. For a free catalog or more information, contact: Colder Products Company, 1001 Westgate Drive, St. Paul, MN 55114. Phone: 651-645-0091. Toll-free: 800-444-2474. Fax: 651-645-5404. Web: cpcworldwide.com

CPC, Colder Products and Colder Products Company are registered trademarks with the U.S. Patent & Trademark office.