



Editorial Contact:
Patty Hoffman
Padilla Speer Beardsley
Tel: (612) 455-1781
E-mail: phoffman@psbpr.com



For a high-resolution image, visit:
<http://www.colder.com/dqda>

Colder Product Company Introduces Innovative 3-Port Dispensing System

DrumQuik[®] 3-Port UDA offers users a reusable chemical-extraction system for virtually any container

ST. PAUL, Minn. – Dec. 15, 2009 – The new DrumQuik[®] 3-Port Universal Dispensing Adaptor (UDA) from [Colder Products Company](http://www.colder.com) enables a pump to be connected to virtually any container. Suitable for use in both low-flow dosing and high-flow transfer pump applications, [DrumQuik 3-Port UDA](http://www.colder.com/dqda) facilitates the connection and disconnection of multiple chemical lines in a process while minimizing chemical exposure and maintaining workplace safety.

“Many processes require the dispensing of multiple chemicals from varied container sizes, and this is often conducted in an unsafe, open manner” according to Tom Braun, business unit manager, Colder Products Company. “We were repeatedly approached by customers seeking a better solution for making multiple chemical-line connections and disconnections without jeopardizing the health and safety of their workers.”

The 3-Port UDA features a 3/4-inch NPT male thread that will mate with common drum bung plugs or bottle caps with a female 3/4-inch thread. The adaptor’s three ports enable liquid removal, venting or blanket gas (N₂, CO₂ or air for pressure dispense) and recirculation if needed. A convenient locking nut is also available for bulkhead mounting applications.

For simplicity in making line connections, Colder quick disconnect couplings can be used with DrumQuik 3-Port UDA. Multiple materials, flow sizes and termination options are available to facilitate transfer of all types of fluid media.

(more)

DrumQuik 3-Port UDA is made from food-grade virgin polypropylene material. It is ideal for a wide variety of chemical use applications, such as pharmaceutical sterilant dispensing, laboratory chemical transfer, the production of fragrances, edible oils and flavorings, paint and coatings mixing, and all manner of institutional cleaning and industrial chemical dispensing.

For more information about pricing and availability, please contact our inside sales department at 651-645-0091 or 800-444-2474.

###

About Colder Products Company

Colder Products Company is a leading provider of quick disconnect couplings to industrial, life sciences and chemical-handling markets. For a free catalog CD or more information, contact: Colder Products Company, 1001 Westgate Drive, St. Paul, MN 55114. Phone: 651-645-0091. Toll-free: 800-444-2474. Fax: 651-645-5404. Web: www.colder.com.

CPC, Colder Products and Colder Products Company are registered trademarks with the U.S. Patent & Trademark office.